

Published: Nov 28, 2006

## Parking Brake Rear Cables (70.35.16)


### Removal

- 1 . Remove the coin tray.




- 2 . Remove the stowage compartment.
- 3 . Remove the adjusting nut and disconnect the front parking brake cable.
- 4 . Release the rear parking brake cables and remove the compensator.




- 5 .  **WARNING: Do not work on or under a vehicle supported only by a jack. Always support the vehicle on safety stands.**

Raise and support the vehicle.


- 6 . Remove both rear wheels and tires.  
For additional information, refer to [Wheel and Tire](#)
- 7 . Tie the rear brake caliper aside.




- 8 . Back-off the parking brake adjuster.



- 9 . Remove the brake disc.




- 10 . Release the cable support bracket, clip and cable-tie.



- 11 . Release the parking brake cable from the body.

- 12 . Disconnect and remove the cable.



13 . Repeat the above procedure for the other side.

## Installation

- 1 . Install the parking brake cable to the hub and connect the nipple.
- 2 . Install the parking brake cable to the body.
- 3 . Connect the cable support bracket, clip and cable tie.
- 4 . Install the brake disc.

**Torque:**  
35 Nm

- 5 . Install the brake caliper.

**Torque:**  
110 Nm

- 6 . Repeat the above procedure for the other side.
- 7 . Install the compensator to the rear parking brake cables.
- 8 . Connect the front parking brake cable and install the adjusting nut.
- 9 . Adjust the parking brake.  
For additional information, refer to [Parking Brake Cable Adjustment \(70.35.10\)](#).
- 10 . Install the coin tray and stowage compartment.
- 11 . Install both wheels and tires.  
For additional information, refer to [Wheel and Tire](#).