


Published: Sep 27, 2006


Rear Door Window Glass

Removal

- 1 . Carefully remove the outer waist seal.



- 2 . If possible, lower the window glass by approximately one third of its travel.
Using the special tool, release the door window glass from the window lift mechanism and raise the glass to the top of the door frame.




- 3 . Secure the glass to the top of the frame.



- 4 . Lower the window lift mechanism.

- 5 . Lower the door glass to the bottom of the door.
Release the lining from both guide channels.



Installation

- 1 . Install the rear door window glass.
Install the guide channel lining.
Secure the glass to the top of the frame.
- 2 . Raise the window lift mechanism.
- 3 . Secure the door window glass to the window lift mechanism.
- 4 . Install the outer waist seal and secure with the Torx screw.