

## Rear Door Latch

### Removal

- 1 . Disconnect the battery ground cable.  
For additional information, refer to [Specifications](#)
- 2 . Remove the window motor and regulator assembly.  
For additional information, refer to [Rear Door Window Regulator and Motor](#)

3 .




**CAUTION:** Release the exterior door handle and screw cover clips from inside the door.

Remove the rear door exterior handle.

For additional information, refer to [Exterior Rear Door Handle](#)


- 4 . Release the remote control cable.
- 5 . Release the door exterior handle mechanism.
- 6 . Remove the rear door latch assembly.




7 . **NOTE:**

Do not disassemble further if the component is removed for access only.

Remove the door latch remote control cable.




- 8 . Release the exterior door handle mechanism cable from the door latch.



## Installation

- 1 . Connect the door exterior handle mechanism cable to the door latch.
- 2 . Install the remote control cable to the door latch.
- 3 . Set the exterior handle mechanism.  
Rotate the lever.  
Engage the retaining tang.



- 4 . Install the door latch and tighten the screws.

**Torque:**  
10 Nm

- 5 . Install the door exterior handle mechanism.
- 6 . Position the remote control cable to the door.
- 7 . Install the rear door exterior handle.  
For additional information, refer to [Exterior Rear Door Handle](#)

- 8 . Install the window motor and regulator assembly.  
For additional information, refer to [Rear Door Window Regulator and Motor](#)
- 9 . Connect the battery ground cable.  
For additional information, refer to [Specifications](#)