

Published: Oct 4, 2006

Rear Door Window Regulator and Motor

Special Service Tools




501-114
Release Lever, Door Glass

Removal


NOTE:

If possible, lower the window glass by approximately one third of its travel.

- 1 . Disconnect the battery ground cable.
For additional information, refer to [Specifications](#)
- 2 . Remove the rear door module.
For additional information, refer to [Rear Door Module \(RDM\)](#)
- 3 . Carefully remove the outer waist seal.




- 4 . Release the door window glass from the window lift mechanism. Raise the glass and secure it to the top of the door frame.
Special Service Tools : [Release Lever, Door Glass](#)



- 5 . Secure the glass to the top of the frame.



- 6 . Remove the window motor and regulator assembly.
Rotate the assembly within the door through 90 degrees and remove the upper edge from the aperture first.



Installation

- 1 . Install the window motor and regulator assembly. Tighten the nuts and the bolts.

Torque:

10 Nm

- 2 . Secure the door window glass to the window lift mechanism.
- 3 . Install the outer waist seal and secure with the Torx screw.
- 4 . Install the rear door module.
For additional information, refer to [Rear Door Module \(RDM\)](#).
- 5 . Connect the battery ground cable.
For additional information, refer to [Specifications](#)