


## Exterior Mirror (76.11.10)

### Removal

#### NOTE:


Removal steps in this procedure may contain installation details.

- 1 . Lower the window glass.
- 2 . Disconnect the battery ground cable.  
For additional information, refer to [Specifications](#)
- 3 . Remove the front door trim panel.  
For additional information, refer to [Front Door Trim Panel \(76.34.01\)](#)
- 4 . Remove the front door frame trim.



E76892

- 5 . **Torque:**  
10 Nm



E76993

## Installation

- 1 . To install, reverse the removal procedure.