

Published: Oct 2, 2006


Exterior Mirror (76.11.10)

Removal


NOTE:

Removal steps in this procedure may contain installation details.

- 1 . Lower the window glass.
- 2 . Disconnect the battery ground cable.
For additional information, refer to [Specifications](#)
- 3 . Remove the front door trim panel.
For additional information, refer to [Front Door Trim Panel \(76.34.01\)](#)
- 4 . Remove the front door frame trim.



- 5 .
Torque:
10 Nm



Installation

- 1 . To install, reverse the removal procedure.