



position of ground wire).

Installation Precautions of Electric Tail gate Lifts 2.To start the engine before installation, check the car dashboard display function, whether the buttons operate normally, whether there is any scratches E.ground wire 3.Check whether the tailgate can normally open and close or not, check if 5. For installation personnel: please remove metal objects and any other hard A.connect to buzzer B.control box port C.connect to the scratching the dashboard; wiring debris need to be tidied up in time, do not leave them in the car; Joints must be well insulated to prevent short circuits. 7.According to our wiring way, to avoid affect the car moving parts, such as steering column, the accelerator and brake pedals, etc., each harness should be A.lock control cable (in) B.lock control cable (in) C.the original tail 8.Connect each harness according to our wiring way(pay attention to the D.the original tail E. control box port ① Joint with back button gate button (out) switching cable C Connect To Control Box Port® Connect To Control Box Port 7










work ball studs,replace with our 18mm ball

studs and 2mm thick pads,both sides



11.Install our latch lock,as the arrow shows



slight interfere,the position which the arrow




19.The dash button installation effect

wiring diagram











23.The connection diagram for the actual 24.Install trim panel and poles, long press tailgate button opening and closing

▲ Car remote control operation: long-press the trunk button

25.If not close the tailgate, it can adjust

the door latch to left or right or more rear

phenomenon, need to put press the rubber

decoration article, to ensure the normal closing

NO:5658513010000

1.To ensure safety and normal usage of our products, please let the professional sales staff to install; to avoid damaging the machine or

on car interior and surface. If any problems, reflect to the customer

objects to prevent car damage during the installation process.

9.Do not change the wires or accessories with the power on.

6.Remove automotive components and place them carefully to avoid

causing accidents, please do not dismantle the products.

immediately.

there is any problem with the lights.

4.Turn off the engine, prepare tools.

fixed after wiring, to avoid getting loose.

▲ All above is subject to change without prior notice. All rights reserved.